



## 071967 Honda CBR1000RR Fireblade Hugger Fitting Instructions

### Kit Includes:

3X	M6 X 16mm Bolts	CBOL0251
3X	Rubber Grommets	CGRO0013
3X	M6 X 6mm Steel Collars	CGRO0017

- Fit the **Rubber Grommets** & **M6 X 6mm Steel Collars** onto the new hugger.
- Using a 5mm Allen key, remove 2 bolts, one from left side and the other from rear top of original chain guard and remove.
- Using the same Allen key remove 2 bolts from either side of original hugger on front end of swing arm, (or cover plate), if no hugger on bike.
- Feed new hugger in from rear over top of tyre with the front end of chain guard carefully going through the gap in the swing arm, on chain side, and under shock gas reservoir canister, above front of swing arm.
- Replace all the original bolts in the same holes with the new **M6 X 16mm Bolts** supplied. It's best to replace the right hand front chromed bolt first, taking care to position the spring bracket, (holding the brake hose/ABS cable), back into the correct positioning hole as it was originally. Leave this bolt loose while working on fitting the remaining three bolts.
- When alignment and clearance all round has been checked, nip up all bolts, but be careful not to over tighten and crack the gell-coat surface of the product.
- Check all fixings periodically.



### Got questions?

[sales@pyramid-plastics.co.uk](mailto:sales@pyramid-plastics.co.uk)

+44 (0)1427 677990

[www.pyramid-plastics.co.uk](http://www.pyramid-plastics.co.uk)



Follow us on social media and feel free to leave us a review!