

## HORNET 900 RADIATOR CHEEKS

### FITTING KIT CONTENTS

4 x m6 x 16mm countersunk allen bolts	CBOL0216
2 x m6 countersunk steel washers	CWAS0002
2 x m6 countersunk black plastic washers	CWAS0200

### STAGE 1

Remove front bolts and aluminium cappings from sides of radiator and aluminium capping directly under tank.

### STAGE 2

Reposition aluminium radiator cappings on inside of radiator cheeks and offer up to bike.  
Attach loosely using 2 m6 x 16mm countersunk bolts and aluminium countersunk washers.  
Replace capping pieces at rear over top of radiator cheeks using the 2 remaining m6 x 16mm countersunk bolts and plastic countersunk washers. When satisfactory fit is established tighten all bolts securely.

## HORNET 900 RADIATOR CHEEKS

### FITTING KIT CONTENTS

4 x m6 x 16mm countersunk allen bolts	CBOL0216
2 x m6 countersunk steel washers	CWAS0002
2 x m6 countersunk black plastic washers	CWAS0200

### STAGE 1

Remove front bolts and aluminium cappings from sides of radiator and aluminium capping directly under tank.

### STAGE 2

Reposition aluminium radiator cappings on inside of radiator cheeks and offer up to bike.  
Attach loosely using 2 m6 x 16mm countersunk bolts and aluminium countersunk washers.  
Replace capping pieces at rear over top of radiator cheeks using the 2 remaining m6 x 16mm countersunk bolts and plastic countersunk washers. When satisfactory fit is established tighten all bolts securely.