

Part # 22132/22138/22139

MT-09 Belly Pan

Kit Contents:

3 x Powder Coated Steel Brackets	CFK22132
2 x Open Rubber Grommets	CGRO0013
2 x Steel Collars	CGRO0017
2 x Flanged Head Socket Screws M6 x 16mm	CBOL0251
2 x flanged head socket screw M6 x 20mm	CBOL2165



Fig 1

Please refer to the pictures as a fitting guide

Before assembly place card or similar protective material under the bike to protect the Belly Pan from accidental damage during Installation.

First fit the open rubber grommets and the steel collar into the larger holes on the sides of the Belly Pan. *Fit the grommet first then slide in the collar.*

Fig 1 shows the correct layout of the brackets. It is for illustration purposes only. Please fit the brackets to the bike first and then attach the Belly Pan.

Fig 2, 3 and 4 show the brackets attached in their correct positions on the engine casing bolts.

The longer 20mm screws fit on the side brackets. The shorter 16mm bolts are for the large bracket mounting point on the underside of the Belly Pan.

Attach everything "finger tight" only to start with. This will allow best possible positioning of the Belly Pan to give even clearance all round before tightening. Check all fasteners **twice** to ensure they are all fully tight.

Please note: the bracket closest to the side stand may need slight adjustment to avoid contact with the side stand. This bracket can be bent by hand.



Fig 2



Fig 3



Fig 4