

# MT-07 Belly Pan Fitting instructions

Part # 22136

## Kit includes:-

2 x Belly Pan Brackets	CFK22136
4 x M6 X 16 Allen Bolts	CBOL0251
4 x M6 Plastic Washers	CWAS0221
4 x M6 Steel washers	CWAS0201
4 x M6 Ny-lock nuts	CNUT0200

We recommend the use of a paddock stand if available, although not essential.

Attach the left (*fig1*) and right (*fig2*) brackets as shown in pictures.

Make sure the O ring is placed on the bolt as shown in *Fig 3* before fully securing the right (*fig 2*) hand side bracket.

Lay a sizable piece of cardboard or cloth underneath the motorbike to rest the belly pan on to help avoid scratching or damaging the item

Using the bolts and washers provided attach the belly pan to the brackets, do not tighten until all bolts have been put into place.



*Fig 1*



*Fig 2*



*Fig 3*

