

MONTAGEANLEITUNG

KOFFERHALTER

Artikel Nr.:4660306



To mount the case holder, proceed as follows:

The front upper brackets of the pannier rack are attached to the original screws of the upper strut suspension mounted from the wheel side.

The bracket is attached to the frame under the seat with the hexagonal screw M6x45 assembled.

The pannier racks are screwed into the holes in the frame behind the bottom front Pillion footrests mounted on the outside with the hexagonal screws M6x20.

After assembly, check all screw connections.