

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

YAMAHA MT-07

FRONT TURN SIGNALS

- 1 Remove bolt on front of side pod cover using a 4mm allen key. (Picture 1)
- 2 Remove (2) bolts behind side pods using a 4mm allen key. (Picture 2)
- 3 Remove (2) bolts on radiator support cover using a 4mm allen key. (Picture 3)
- 4 Take stock blinker and remove clip. (Picture 4/5)
- 5 Unplug from OEM harness and slide stock turn signal off.
- 6 Take NRC blinker, unscrew little tab, slide harness through stock housing and mount by screwing the little tab back onto the blinker. (Picture 6)
- 7 The LED flasher relay supplied for your kit has an installation video directly on the product page: [here](#).

