

VFR800i HUGGER

Part # 071092

Fitting kit:

1 x Bracket	CFK071094
2 x M6 x 12mm button allen bolt	CBOL0123
2 x M5 x 16mm allen bolts	CBOL0162
2 x Nylon washer	CWAS0230
2 x M6 s/steel washer	CWAS0201
2 x 430mm cable tie	CAB0430

Fitting instructions:

N.B.

At Pyramid we pride ourselves on the quality of our hugger fitting kits and usually avoid the use of cable ties. In this instance we felt the use of a cable tie, with the hugger moulding specifically designed to make mounting as secure and neat as possible, was preferable to using a large steel bracket.

Remove the two screws that retain the hose clips on top of the chain guard. Position the bracket on top of the clips and secure with the M5 bolts supplied, using loctite.

Pass the cable tie through from the front of the lower extension, up and back down through the hole in the “nose”. Leave approx 50mm of the cable tie protruding through the lower hole.

Position the hugger and secure to the bracket using the M6 bolts, **but do not fully tighten at this stage.**

Pass the end of the cable tie down through the swing arm and out to the left and attach the other end. Ensure that the cable tie does not pass through the spring.

Check the hugger alignment and tighten the cable tie.

Finally remove and refit the M6 bolts using the s/steel and nylon washers and loctite or a similar thread retaining compound.

Please note: check hugger alignment and fasteners periodically.