

072432 Yamaha XT1200Z Super Ténéré Hugger Fitting Instructions


Kit Includes:

1X	C072432	Moulding
2X	CBOL0251	M6 X 16mm Flange Headed Bolts
2X	CWAS0221	M6 Plastic Washers
2X	CNUT0200	M6 Nyloc Nuts
1X	CWAS0403	M10 Nordlock Washer
1X	CFK072432 / CBUM003	Bracket + Rubber Button

Note: Does not fit with Akrapovič exhaust systems.

Please enquire with us to get the correct washer for the Akrapovič exhaust system.

- The bracket mounts on the upper inside bevel box mounting stud. Remove this nut, leave the washer in place, and fit the M10 Nordlock washer over the stud. Position the bracket over the stud with the rubber button resting on the swing arm and refit the nut using loctite or similar thread retaining compound.
- Remove the two bolts fixing the caliper tension bar leaving the bar in place.
- Slide the hugger over the tyre with the bracket fitting on the inside of the hugger and the hugger fitting over the tension bar.
- Re-fit the tension bar bolts and finger tighten.
- Fit the two M6 x 16mm flange headed bolts with the M6 plastic washers to the bracket mountings with the two M6 Nyloc nuts (finger tighten).
- Check hugger alignment and fully tighten all fixings.
- Check all fixings periodically.



Got questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!

**SUPER
TENERE**

