

082400 **PYRAMID** BMW R1200/1250GS Spray Guard Extension Fitting Instructions

Kit Includes:

1X C082400	Moulding
2X CBOL0022	M4 X 16mm Bolt
2X CWAS0010	M4 Washer
2X CNUT0120	M4 Anchor Nut
4X CBUM003	Rubber Pad
1X CGRA001	Spray Suppression 265mm X 45mm

This product will require you to drill two holes in the original BMW guard to provide a reliable mechanical fixing.

- Remove the original BMW Spray Guard from its mounting point on the end of the Swinging Arm. Unscrew the 3 bolts holding it in place.
- The two pre-installed M4 Anchor Nut fasteners provide an accurate drilling 'jig' whilst drilling the holes for fixing.
- Please note, as shown in this picture of the installed Pyramid part, that the longer guard extension element is located at the lower end of the original BMW spray guard. You should start working from this lower fixing point.



- Position the Pyramid spray guard centrally. Using a 3mm drill-bit, drill through the threaded insert in the M4 Anchor Nut fastener. Open up the hole in the BMW original with a 5mm drill. Repeat this step at the other mounting point.
- Finally attach the Pyramid spray guard extension to the BMW original using the M4 x 16mm bolts and M4 washers - then re-install the complete unit on the bike.

Any questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!

GS