

1.	X1	C08670	Wind Deflector
2.	X1	CBOLM50009	M5 x 20 Flanged Head Bolt
3.	X1	CSPAM60011	Spacer
4.	X4	C090001	3M Dual Lock Strip (25mm x 12.5mm)

Assembly Instructions

Begin by removing the OEM Bolt to gain access to the mounting point. See '**FIG. 1**' for reference.

Attach the 3M Dual Lock strips (Item 4) to the inside of the wind deflector as shown in '**FIG. 2**'. Repeat on both sides. Check the alignment of the wind deflector with the fairing on the motorcycle and remove the backing film when confident with the fitment location.

Using the remaining fixings provided (Items 2 and 3), loosely fit the Wind Deflector (Item 1) to the mounting point referenced in **FIG. 1**, see '**FIG. 3**' for reference.

Once the Wind Deflector is in the correct position, apply pressure on the 3M Dual Lock strips to ensure good adhesion. Now fully tighten the central fixing.

