

XJR1300 BELLY PAN

Part # 22100/22101

Contents:

4 x brackets	CFK22100
4 x M6 x25mm c/sunk allen bolt	CBOL0221
4 x M6 c/sunk s/s washer	CWAS0002
4 x M6 steel washer	CWAS0201
4 x M6 nyloc nut	CNUT0200
4 x 13mm grommets and spacer	CGRO0013/CGRO0017

Fitting instructions:

Remove the bolts from the steadying brackets at the front of the engine and loosen the main bolt which passes through all three brackets. Place the “B” shaped brackets (A2) between the engine steadying brackets and the frame and then refit the bolts. The “B” shaped brackets should be stamped to show which is left and right, but if not the “B” bracket should face forwards to line up with the steadying brackets at the front of the engine. Now tighten all the bolts.

Remove the cut-out switch on the kickstand and place the “U” shaped bracket marked B1 behind it. Now refit the switch.

Remove the two lower bolts from the crank case on the right hand side and fit the “Y” shaped bracket marked B2. Refit the bolts.

With all four brackets now in place, fit the grommets and the spacers provided in the holes in the product. Ensure that all the bolts are tight. Now fit the product in place using the fixings supplied. Fit the two front fixings loosely at first and then fit the rear fixings. Tighten fully once all four bolts are in place.

NB: this product reduces ground clearance. It is advisable to adjust the suspension to compensate, especially if heavy loads are to be carried.

