

Kit contains: 6 x metal brackets marked left and right CFK22115
 10 x M6 x 20mm mushroom head bolts CBOL2165
 2 x M6 flat washers CWAS0201
 2 x M6 nylock nuts CNUT0200
 2 x large jubilee clips CFIT0025
 2 x small jubilee clips CFIT0040
 2 x lugnuts CNUT0211

Left, right and centre panels

Hints for fitting : All dimensions shown are as a guide only. Brackets should be fitted loosely at first until panel alignment is achieved.

For ease of identification, the bottom frame tube mounted bracket has no threaded insert and is fitted with the smaller of the 2 jubilee clips.

Apply protective tape to the frame tubes before attaching brackets to prevent paintwork damage (insulation tape).

Check the threads of captive nuts are clean. Powder coating deposits may cause tightness.

Fit centre panel after 2 side panels have been loosely positioned. The 2 underside fasteners of the centre panel should be fitted first.

Use a stubby screwdriver! There will be less chance of slipping and scratching the paintwork!

