

Super Tenere XT1200Z 2010 > Frame Infill Panel Part # 22125A

Contents

2 x M8 x 40mm dome head allen bolt – CBOL0305

1 x small cable tie – CAB0200

2 x 4mm thick washer – CWAS0232

Fitting Instructions

- Remove the pillion foot peg from the right hand side of the bike
- Fit the panel to the bike with the pillion peg over the top of the panel using the M8 x 40mm bolts provided. (don't fully tighten). On the carbon fibre version fit the 2 plastic spacers supplied on the inside of the panel.
- Feed the cable tie through the slot in the rear of the panel and then through the small hole in the frame.
- Fully tighten the pillion peg fixings and pull the cable tie until it holds the panel firmly at the back.
- **Check all fixings periodically.**

Super Tenere XT1200Z 2010 > Frame Infill Panel Par # 22125A

Contents

2 x M8 x 40mm dome head allen bolt – CBOL0305

1 x small cable tie – CAB0200

2 x 4mm thick washer – CWAS0232

Fitting Instructions

- Remove the pillion foot peg from the right hand side of the bike
- Fit the panel to the bike with the pillion peg over the top of the panel using the M8 x 40mm bolts provided. (don't fully tighten). On the carbon fibre version fit the 2 plastic spacers supplied on the inside of the panel.
- Feed the cable tie through the slot in the rear of the panel and then through the small hole in the frame.
- Fully tighten the pillion peg fixings and pull the cable tie until it holds the panel firmly at the back.
- **Check all fixings periodically.**