



22161 Yamaha MT-09 Fly Screen Fitting Instructions

Kit Includes:

1X	C22161	Fly Screen
4X	CBOL2179	M6 X 20mm Black Stainless Bolt

- Remove the bolts from the headlight on the MT-09. Use the bolts supplied in conjunction with the OEM metal washers from the headlight to fit the Pyramid fly screen. Be sure to check fixings periodically.



Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!



22161 Yamaha MT-09 Fly Screen Fitting Instructions

Kit Includes:

1X	C22161	Fly Screen
4X	CBOL2179	M6 X 20mm Black Stainless Bolt

- Remove the bolts from the headlight on the MT-09. Use the bolts supplied in conjunction with the OEM metal washers from the headlight to fit the Pyramid fly screen. Be sure to check fixings periodically.



Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!



22161 Yamaha MT-09 Fly Screen Fitting Instructions

Kit Includes:

1X	C22161	Fly Screen
4X	CBOL2179	M6 X 20mm Black Stainless Bolt

- Remove the bolts from the headlight on the MT-09. Use the bolts supplied in conjunction with the OEM metal washers from the headlight to fit the Pyramid fly screen. Be sure to check fixings periodically.



Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!