

BMW K1200R/K1300R Replacement Screen

Part # 244091/244100

Fitting Instructions

1. If you have the 09 K1300R version of the bike you will need to take the fluted grey plastic headlight cover off before fitting the screen. This can easily be done by using a T25 Torx Star Bit socket spanner on both of the two recessed retaining bolts at the bottom of each side of the headlight cluster. Take headlight cover off and replace bolts to same torque tightness as previously.
2. On both 05/08 K1200R and 09 K1300R models use a T25 Torx Star Bit socket spanner to remove all four bolts, plastic washers and original screen.
3. Offer up replacement screen and replace all four bolts and washers, starting with the two on the sides first for ease of fit.

While screwing bolts up, you might need to feed a hand in from the rear of the screen and squeeze the retaining nuts, (encapsulated in rubber isolation mountings), outwards to get an initial bite with bolts to lock up tight again.

Make sure that new screen is as secure as old one was before riding off.