

24444 BMW F900R & F900XR Shock Shield Fitting Instructions

Kit Includes:

1X	C24444	Rubber Flap
1X	CFK24444	Bracket
2X	CBOL0105	M5 X 10mm Stainless Bolt
1X	CBOL0123	M6 X 12mm Stainless Bolt
2X	CNUT0150	M5 Stainless Nyloc Nut
2X	CWAS0100	M5 Washer

- The Pyramid Shock Shield is simple to fit. Attach the rubber flap to the Bracket using the **M5 X 10mm Stainless Bolts**, **M5 Stainless Nyloc Nuts** & **M5 Washers**.
- Remove the nut cap and nut from the side of the alternator regulator (**see Fig 1**). Refit the nut and nut cap with the Pyramid Shock Shield incorporated.
- On the left-hand side of the bike, use the **M6 X 12mm Stainless Bolt** to attach the other end of the Pyramid Shock Shield (**see Fig 2**).
- Check fixings periodically.

Any questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!

