



32102 Yamaha MT-10 Rear Peg Blanking Blocks **Fitting Instructions**

2X	Blanking Blocks (pair)	C32102
4X	Bolts	CBOL0304
4X	Washers	CWASM80001

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



This product is easy to fit! Simply remove the pillion foot pegs and fit blanking blocks using the bolts and washers provided.



32102 Yamaha MT-10 Rear Peg Blanking Blocks **Fitting Instructions**

2X	Blanking Blocks (pair)	C32102
4X	Bolts	CBOL0304
4X	Washers	CWASM80001

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



This product is easy to fit! Simply remove the pillion foot pegs and fit blanking blocks using the bolts and washers provided.



32102 Yamaha MT-10 Rear Peg Blanking Blocks **Fitting Instructions**

2X	Blanking Blocks (pair)	C32102
4X	Bolts	CBOL0304
4X	Washers	CWASM80001

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



This product is easy to fit! Simply remove the pillion foot pegs and fit blanking blocks using the bolts and washers provided.



32102 Yamaha MT-10 Rear Peg Blanking Blocks **Fitting Instructions**

2X	Blanking Blocks (pair)	C32102
4X	Bolts	CBOL0304
4X	Washers	CWASM80001

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



This product is easy to fit! Simply remove the pillion foot pegs and fit blanking blocks using the bolts and washers provided.