

30700 Royal Enfield Himalayan / Guerrilla 450 Handguards Fitting Instructions

Kit Includes:

1.	X2	C30203M	Handguards (pair)
2.	X1	CFK30700A	Bracket (LHS)
3.	X1	CFK30700B	Bracket (RHS)
4.	X4	CBOLM50007	M5 x 16mm Bolt
5.	X4	CWASM50002	M5 Washer
6.	X4	CNUTM50002	M5 Nyloc Nut
7.	X4	CSPAM50003	M5 Collar
8.	X2	CBOLM60018	M6 x 50mm Countersunk Bolt
9.	X2	CWASM60006	M6 Countersunk Washer

Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and feel free to leave us a review!

Loosely attach all fixings initially - fully tighten once all other steps are completed.

Assembly Instructions

- Begin by removing the bar-ends and mirrors from the motorcycle.
- Attach the Pyramid handguards to the bar-ends using the M6 x 50mm countersunk bolt (item 8) and M6 countersunk washers (item 9). See Fig. 2
- Attach the corresponding bracket to the Pyramid handguard using the supplied M5 fittings (items 4, 5, 6, and 7). See Fig. 2
- Secure the brackets to the motorcycle using the mirrors. It is possible to reorientate the position of the mirrors when fully fitted by adjusting the two nuts on each mirror.

Please Note: Pyramid advise that all fixings are checked periodically.

