

ZX6 95-97 Hugger

PART # 07312

Hugger Fitting Instructions

Fittings: a) 1x Strap bracket for right hand swinging arm (2 pieces) – CFK07311
b) 4x M6x16 Stainless steel Allen bolts – CBOLM60008
c) 1x M6x12 Stainless steel dome head bolt – CBOLM60007
d) 4x Black plastic washers – CWASM60003
e) 1x M6 shake proof washer –CWASM60002

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

PLASE NOTE. From 1997 on the configuration of the rear shock absorber remote reservoir was changed and the “banjo” connector on the back inside of the reservoir catches the edge of the Hugger as the suspension compresses. In order to avoid this loosen the two fasteners and rotate the reservoir to allow for better clearance.

The Job is easier with the bike on a paddock stand.

First remove the chain guard and the exhaust can.

To fit the right hand side bracket, first pull the brake hose away from its wire-formed retaining ring. With the hose clear, mount the strap bracket (a) by loosely attaching the single underside fastener (c)&(e).

Offer up the Hugger and attach loosely to the chain side using 2x (b) and (d)
Attach to the right side bracket using 2x (b) and 2x (d).

NOTE. Both fingers of the bracket should be inside the Hugger.

Re-fit the brake hose making sure it is correctly routed.

Fully tighten all fasteners checking left/right alignment over the tyre as you do so.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.