

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

YAMAHA XSR 700

FRONT TURN SIGNALS

- 1 Remove (2) bolts on headlight using a 4mm allen key. There is one on each side of the headlight. You can rest the headlight forward. (Picture 1)
- 2 Unplug turn signal connectors. (Picture 2)
- 3 Remove clip behind turn signal bracket with a small flat head screwdriver. (Picture 3)
- 4 Remove (3) bolts using a 6mm allen key. (Picture 4)
- 5 Take new turn signals, and remove the philips head screw to separate the (2) clear plastic blocks.
- 6 Mount signal on the outside of the bracket, feed the plastic block through hole, and re-use that philips head screw to secure on the backside. (Picture 5)
- 7 Repeat on both sides.

