

TRX850 Hugger

Part # 07212

Hugger Fitting Instructions

Fittings: a) 2x CBOLM60007 M6x12 Stainless dome Head Allen Bolts
 b) 2x CWASM60003 M6 Black Plastic Washer
 c) 1x CFK07211 Bracket

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

The Job is easier with the bike on a paddock stand.

1. First remove the chain guard and right hand side Exhaust can.
2. Remove the brake hose guide.
3. Feed the hugger in over the wheel.
4. Fix the bracket to the hugger using the 2x (a) and 2x (b).
5. Attach loosely to the chain side using original bolts.
6. Replace the break hose guide and mount it on top of the hugger bracket.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.

NOTE!:

ALL PYRAMID PRODUCTS ARE DESIGNED USING THE FACTORY STANDARD BIKES WITH STANDARD TYRES ETC... SO ANY LARGER SIZE TYRES MAY AFFECT THE FIT.