

Kit Includes:

1.	X1	C39705	Exhaust Guard
2.	X1	CFK39705A	Bracket A
3.	X1	CFK39705B	Bracket B
4.	X5	CBOLM50005	M5 x 12mm Bolt
5.	X10	CWASM50002	M5 Washer
6.	X5	CNUTM50002	M5 Nyloc Nut

OEM:

7.	X3	-	OEM M6 Bolt
----	----	---	-------------

Assembly Instructions

- Start by removing the OEM M6 bolts and fit bracket A using the same bolts as shown in **Fig 1**.
- The remaining mounting points are fitted up using the arrangement shown in **Fig 3**.
- Attach bracket B as shown in **Fig 2** (to the rear of bracket A).
- Fit the exhaust guard using the remaining fittings as shown in **Fig 4**.
- Check fixings periodically.

