

21845 Honda CB1000 Hornet Fly Screen Fitting Instructions

Kit Includes:

1.	X1	C21845	Fly Screen
2.	X1	CFK21845A	Bracket
3.	X1	CFK21845B	Mounting Tab <i>(pre-fitted by Pyramid)</i>
4.	X2	CBOLM60007	M6 x 12mm Flanged Button Head Bolt
5.	X2	CNUTM60008	M6 Cage Nut
6.	X2	CCAP0002	M6 Bolt Cap
7.	X2	CSCR0004	No.10 Flanged Button Screw
8.	X2	CSPAM80002	Spacer
9.	X2	C090001	3M Dual Lock (2x 25mm Square)

Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!

Assembly Instructions

- Start by attaching the cage nuts to the bracket, as shown in **Fig 1**.
- Remove the OEM bolts from the back of the TFT display and fit the bracket, as shown in **Fig 2**. Fully tighten.
- Attach the 3M Dual Lock to the mounting tab, as shown in **Fig 3**. Remove the backing from one 25mm square and stick it to the mounting tab. Fit the remaining 25mm square into place using the Dual Lock mechanism, then remove the backing, ready for fitment to the motorcycle.
- Ensure the headlight cowl is free of debris before moving on to the next step.
- Position the fly screen and attach it using the remaining fittings shown in **Fig 4**. Once fully tightened, apply some pressure to the pointed edge of the fly screen to ensure good adhesion of the 3M Dual Lock.
- Fully tighten all fittings. Be sure to check all fixings periodically.

