



Decal Application Instructions

- Be sure to work indoors on a clean surface.
- Thoroughly clean the product you are applying the decals to. Making sure there is no dust or dirt present is important for getting the best bond between the adhesive and product.
- You will need a water solution mixed with 4-6 drops of washing up liquid or soap, along with either a squeegee or credit card.
- With a soft sponge/cloth, apply the water solution to the designated area of the product. It is important to cover the whole area you plan to apply the decal to, this makes it easier to position on the product.
- Remove the backing paper and be sure to avoid the adhesive side of the Decals. The more contact you make with the adhesive, the less effective it will be after application.
- Lay the decal onto the product and move into position. The water allows enough movement for optimum placement on the product.
- Once you are happy with the placement of the decal, use the squeegee or credit card to squeeze out any water and air from beneath the decal. Work from the center towards the edges. Once all the water is squeezed out, the adhesive will kick in.
- Leave the decal to cure for at least 10 minutes.
- **Note: Clear Application Tape Removal (if included):**
If your decal kit comes with application tape installed, follow all the previous steps, let the decal cure for at least 10 minutes and then carefully peel off the application tape at a 45-degree angle, it is important to make sure the decal remains on the surface while peeling off the application tape.



A video guide on how to apply decals can also be found over on our YouTube Channel!



@pyramidmoto86

Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk