

36001M Triumph Speed 400 Blanking Blocks 2023> Fitting Instructions

Kit Includes:

1.	X1	C36001A	Blanking Block (LHS)
2.	X1	C36001B	Blanking Block (RHS)

OEM Parts (From the Motorcycle):

3.	X4	OEM M8 Bolt
----	----	-------------

Assembly Instructions

- Begin by removing the OEM Grab Rail to gain access to the mounting points shown in '**FIG. 1**'.
- Loosely attach the RHS Blanking Block (**Item 2**) to the mounting points using the OEM M8 Bolts (**Item 3**).
- Repeat the above step for the LHS Blanking Block (**Item 1**).
- Once the Blanking Blocks are in the correct position, fully tighten all fixings.

FIG. 1

OEM M8 Bolts
RHS Mounting Points



Please Note:

We advise that all fixings
are checked periodically.

Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!



RHS Blanking Block