



36099 Triumph Blanking Blocks Fitting Instructions

Kit Includes:

1.	X2	C36099	Blanking Blocks (pair)
2.	X4	CBOLM80017	M8 x 12mm Bolt

Assembly Instructions

- Remove the original rear footpegs.
- Fit the Pyramid blanking blocks using the four M8 x 12mm bolts supplied.
- Check fixings periodically.



Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!



36099 Triumph Blanking Blocks Fitting Instructions

Kit Includes:

1.	X2	C36099	Blanking Blocks (pair)
2.	X4	CBOLM80017	M8 x 12mm Bolt

Assembly Instructions

- Remove the original rear footpegs.
- Fit the Pyramid blanking blocks using the four M8 x 12mm bolts supplied.
- Check fixings periodically.



Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!



36099 Triumph Blanking Blocks Fitting Instructions

Kit Includes:

1.	X2	C36099	Blanking Blocks (pair)
2.	X4	CBOLM80017	M8 x 12mm Bolt

Assembly Instructions

- Remove the original rear footpegs.
- Fit the Pyramid blanking blocks using the four M8 x 12mm bolts supplied.
- Check fixings periodically.



Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!



36099 Triumph Blanking Blocks Fitting Instructions

Kit Includes:

1.	X2	C36099	Blanking Blocks (pair)
2.	X4	CBOLM80017	M8 x 12mm Bolt

Assembly Instructions

- Remove the original rear footpegs.
- Fit the Pyramid blanking blocks using the four M8 x 12mm bolts supplied.
- Check fixings periodically.



Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!