

Avant GS 1300

Front Fender Extension

Installation Guide

Fits: **2024+ BMW R1300 GS**



Care Instructions:

Clean with soap and water.
Armor-All works well to restore appearance.

Tool Required:

Torx T25 Screwdriver

Parts:

- 1 Avant
- 1 Sheet Protection Film
- 2 Avant Brackets + 10mm T25 Torx Screws

* PLACE THE BIKE ON ITS CENTER STAND ON LEVEL GROUND.

*Turn the handlebars for installation convenience.
Clean the top side of your front fender.*

- 1** Avant features two threaded mounting brackets to assure tight assembly with the fender.
- 2** Apply the Protection Film to the bottom of the front fender aligning its edges to the fender. The film can be repositioned, if needed, by lifting and re-applying it to best align with the Avant.



- 3** Slip the Avant over the front fender until the tip of the fender fits snugly into the receiving shoe. Make sure the sides fit up against the fender's side edges.
- 4** Position a mounting bracket with your fingers behind the mounting flange in-between the raised ribs.

The **bracket gripping edge faces the inside of the fender.**



- 5** Pre-tighten the screw with a **T-25 Torx driver**. Install the opposite side bracket in the same way. Check final alignment and tighten both screws securely.
- 6** **Re-check screw tightness after the first ride**, and periodically thereafter.



Copyright 2024 Machineart Inc. All Rights Reserved.

WARNING AND DISCLAIMER: All parts manufactured, designed or sold by MachineartMoto ("MaMo") should be installed by a qualified motorcycle technician. The risk of injury is increased by improper installation or misuse of equipment. MaMo's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles.