



35790M Royal Enfield Himalayan / Guerilla 450 Horn Guard 2024> Fitting Instructions

Kit Includes:

- | | | | |
|----|----|--------|------------|
| 1. | X1 | C35790 | Horn Guard |
|----|----|--------|------------|

Please note: No additional fixings are required for the installation of this product.

OEM Parts (From the Motorcycle):

- | | | |
|----|----|-------------|
| 2. | X1 | M8 OEM Bolt |
|----|----|-------------|

Assembly Instructions

The Pyramid Horn Guard utilises the existing mounting location for the motorcycle horn. Please ensure the Horn is supported when removing the bolt for installation in order to avoid any unnecessary damage.

- Begin by removing the existing M8 bolt (Item 2). As mentioned above, please be aware that the Horn will fall as the bolt is being removed.
- Place the Pyramid Horn Guard (Item 1) over the Horn, aligning the holes. Re-insert the bolt and tighten it so that both the Horn and the Horn Guard are secure. Use '**FIG. 1**' for reference.
- Ensure the Horn returns to its original position by pressing it against the notched framework on the Motorcycle. Adjust the position of the Horn Guard as required to ensure that it covers the Horn correctly. Once in position, tighten until significant resistance is detected.
- The Horn Guard has now been fully fitted.

Please Note: We advise that all fixings are checked periodically.

FIG. 1



Any questions?
sales@pyramidmoto.co.uk
+44 (0)1427 677990
www.pyramidmoto.co.uk



Follow us on social media and
feel free to leave us a review!