

51202 Yamaha XSR900 Tail Tidy Fitting Instructions

Kit Includes:

- 1X Tail Tidy
- 1X Blanking Plate
- 1X Rubber Bung
- 4X M6 Stainless Bolt
- 4X M6 Stainless Washer
- 4X M6 Stainless Nyloc Nuts
- 4X Aftermarket Indicator Adapter
- 2X Ring Adapters (for use with OEM indicators)
- 3X Cable Tie
- 1X LED Number Plate Light + wiring
- 1X Reflector Dot

Fitting this tail tidy is simple - if in any doubt, seek help from a qualified mechanic.

- Remove the seat and then the seat catch bracket to gain access to the wiring (4 bolts to remove).
- Disconnect the indicator and number plate light wiring sockets.
- Remove the OEM tail unit by unbolting the 4 nuts. Take care with the wiring when removing the OEM tail unit.

Re-using OEM indicators?

Remove the OEM indicators from the OEM tail unit. Fit the OEM indicators to the tail tidy using the ring adapters supplied.

Using aftermarket indicators?

The aftermarket indicator adapters supplied can be used in this instance.

- Fit the LED number plate light to the tail tidy. Fit the tail tidy and blanking plate using the M6 bolts, washers and nyloc nuts supplied. Route the wiring as shown in the image below.
- Attach all the wiring. The extra length of wire supplied will need to be used with the LED number plate light. Now is the best time to check that the indicators are routed correctly.
- Re-fit the seat catch bracket which was removed in the first step.
- Fit the number plate to the tail tidy.
- It is important to check that the clearance between the bike and the tail tidy is sufficient. Ensure that passengers/luggage/suspension adjustment will not cause any contact.
- The rubber bungs supplied can be used to protect the key lock.

Check fixings periodically.

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and
feel free to leave us a review!

